

Product:	DryGrip	
REF:	902	
Manufacturer:	DACH Schutzbekleidung GmbH & Co. KG	

Classification:	▪ CAT I according to the Personal Protective Equipment (PPE) Regulation (EU) 2016/425. ▪ Helmke Drum Test accordingly IEST-PR-CC003.5: Category II We recommend the use in clean rooms accordingly EN ISO 14644-1: ISO class 6 to 9.		
Materials:	▪ Inside: Polypropylene nonwoven ▪ Outer surface: slip-resistant Polyethylene-coating ▪ Elastic: Natural rubber		
Product description:	The DryGrip is a robust polypropylene shoe cover made of spunbond nonwoven, which is fully coated with a 0.13 mm thick fluid resistant film on the outer surface. The primary advantages of the outer layer are: ▪ extremely durable ▪ completely waterproof ▪ guaranteed slip-resistant The comfortable and flexible foot opening has an ultrasonic welding, which is form-fitting to the foot and offers a very pleasant wearing comfort. As a universal size the DryGrip fits every foot perfectly. It is ideal for use in the food, beverage and pharmaceutical industries as well as in catering, cleanrooms and GMP zones.		
Size:	Length (cm)	Width (cm)	Foot opening (cm)
	42 +/- 1	16,5 +/- 1	13,5 +/- 1
Colour:	White		
Packaging and variants:	Packaging	Quantity (pcs.)	GTIN
	Bag	100	4049825008057
	Shipping Carton	500	4049825508045
	Euro pallet	12.500	-

Shelf life:	Store dry in original packaging without direct sunlight (see packaging). If the storage conditions are observed, the product has a storage life of 10 years (see labeling on the product).
Environmental sustainability and disposal:	In the case of contaminated products the type and extent of contamination determines the disposal; the applicable laws and regulations of the respective country must be observed. A non-contaminated product can be thermally utilised or disposed of in landfills without releasing toxic substances.