


Product:	Overall Classic	
Trademark:	SAFE®	
REF:	53	
Manufacturer:	DACH Schutzbekleidung GmbH & Co. KG	

Classification:	CAT I according to the Personal Protective Equipment (PPE) Regulation (EU) 2016/425.
Materials:	<ul style="list-style-type: none"> ▪ Nonwoven fabric: Pure polypropylene ▪ Elastic: latex-free synthetic elastomer ▪ Sewing thread: 100 % polyester
	All materials used are free of irritants.
Product description:	<p>The protective suit Overall Classic consists of a body part, long sleeves and long trouser legs and a hood sewn on with an overlock seam.</p> <p>The suit is provided with an opening in the front which is equipped with polyester zipper for closing.</p> <p>The size of the suit exceeds the standard sizes specified for Europe and the USA and is optimized for freedom of movement.</p> <p>The protective suit is provided with an elastic band in the face, arm, leg and waist bound in overlock stitching.</p> <p>Conforms to the HACCP concept.</p>
Sizes and Colours:	<p>S – XXXL in Blue</p> <p>L - XXL in Green</p>

Packaging and variants:	Quantity	Packaging
	1 pc.	Bag
	50 pcs.	Shipping carton
GTIN:	53B/S	4049825011798
	53B/M	4049825011804
	53B/L	4049825000884
	53B/XL	4049825000891
	53B/XXL	4049825000907
	53B/XXXL	4049825011811
	53G/L	4049825011842
	53G/XL	4049825000914
		53G/XXL
Storage:	<p>Store dry in original packaging without direct sunlight. See also packaging.</p> <p>If the storage conditions are observed, the product has a storage life of 10 years.</p>	
Environmental sustainability and disposal:	<p>In the case of contaminated products, the type and extent of contamination determines the disposal, and the applicable laws and regulations of the relevant country must be followed.</p> <p>A non-contaminated product can be thermally recycled or disposed of in landfills without releasing toxic substances.</p>	
Warnings:	<p>This protective suit is not suitable for fire protection, as there is a risk of dripping in the event of ignition and the fabric is not self-extinguishing.</p> <p>Therefore, avoid contact with open flames.</p>	