



GP3 Plus



Neutral eye protection

Description and composition:

Made of clear polyvinyl chloride (PVC) with a panoramic 1.5 mm polycarbonate lens.

With a universal nose bridge and a 12 mm wide elastic strap.

It has 4 ventilation valves that provide indirect ventilation to help prevent fogging.
Can be used over prescription spectacles.

With no metal parts.

Weight: 86 g

0%
metal

4 ventilation
valves



Front in PVC:
comfortable and
flexible



Adjustable elastic
strap

Ref.	Product	Lenses MARKING	Frame MARKING
902299	Polycarbonate spectacles. Anti-fogging and anti-abrasion treatment	M 1 B CE	M EN166 3 B CE

Neutral eye protection

Standard and certification	EN 166		
Applications	High impact protection. Also protects from drops of liquid. Sectors: chemical-pharmaceutical, painting, plastics, wood, agriculture, construction, etc. Also for hot environments or when the worker is exposed to different temperatures.		
Conservation Storage - Expiry	In order to maintain the spectacles in good condition, keep them in a clean, dry place in their appropriate case.		
Directions Use	Cleaning: use warm water and a neutral soap. Do not use abrasives or solvents. Rinse in water and dry with a soft cloth. Medop anti-fogging cleaning spray is also recommended. We advise regular inspection of the protectors, and their replacement if they have deteriorated in any way. Please ensure that the risk present in the workplace corresponds with the field of use of these protectors.		
Presentation	10 units per box. 20 boxes per carton.		
Bar code	902299	GIN-13: 8423173110406	GIN-14: 48423173110404

