


K201 | Visitor Goggles | Product Data Sheet

Product:	Visitor Goggles	
REF:	K201	
		
Classification:	CAT II Personal Protective Equipment accordingly Regulation (EU) 2016/425.	
Protection class:	Protective goggles accordingly EN 166. <ul style="list-style-type: none"> ▪ Lense Marking: M 1 F CE ▪ Frame Marking: M EN166 F CE 	
Material:	Clear Polycarbonate	
Product description:	<p>The Visitor Goggles are metal-free spectacles, with single-piece front and lens made of the most robust polycarbonate. Excellent upper protection with a seal that makes the entry of particles difficult. Polycarbonate temples provide side protection, with 6 vertical openings to encourage anti-fogging. They may be used as visitor's goggles or used over prescription glasses.</p> <p>Recommended for use as visitor's spectacles due to the following characteristics:</p> <ul style="list-style-type: none"> ▪ Front and lens made of one piece of polycarbonate, a material that is very impact-resistant. ▪ Wraparound design with a wide field of vision. ▪ Lens is 2 mm thick, dimensions of 152 x 60 mm. ▪ F marking: Protection against low-energy impacts. <p>This model can be used for agricultural activities, automobiles, textiles, construction or as visitor's goggles.</p>	
Packaging:	Quantity	Pakaging
	12 pcs.	Box
	300 pcs.	Shipping Carton
Storage:	In order to maintain the goggles in good condition, keep them in a clean, dry place in their appropriate case.	
Directions and use:	Cleaning: use tepid water and a neutral soap. Do not use abrasives or solvents. Rinse in water and dry with a soft cloth. We advise regular inspection of the goggles, and their replacement if they have deteriorated in any way. Please ensure that the risk present in the workplace corresponds with the field of use of these goggles.	