

<b>REF:</b>	180W
<b>Product name:</b>	Cleanroom Hood
<b>Trademark:</b>	SAFE®
<b>Manufacturer:</b>	DACH Schutzbekleidung GmbH & Co. KG



<b>Classification:</b>	Category I Personal Protective Equipment Regulation (EU) 2016/425	
<b>Product description:</b>	<p>The hood consists of a headpiece, two side parts and a shoulder cover piece. These pieces are sown together with an overlock-seam. The highly sophisticated product shape ensures freedom of movements for the consumer without the hood slipping uncontrollably.</p> <p>Elastics in the facial area and on the connecting seam of the shoulder cover piece and the head cover piece, ensure maximum closure and therefore optimal protection. Protects the wearer from tangling of hair in the wearer's immediate working environment. The shoulder cover covers the area around the shoulders and chest area.</p> <p>Product tests under high mechanical stress and highly dynamic movement simulation particle emission show that this hood is well suitable for cleanrooms.</p>	
<b>Material:</b>	Hood:	100 % polypropylene non-woven fabric, antistatic treated
	Elastic:	polyurethane elastomere, free from natural latex
	Sowing thread:	100% Polyester
<b>Tests:</b>	<p>IEST-PR-CC003.3 Helmke Drum Test Test results: Class II-III</p>	We recommend the usage in cleanroom classes 4-9, according to DIN EN ISO 14644-1.
<b>Dermatological Tolerance:</b>	No intolerance reactions.	

<b>Standard colour:</b>	White		
<b>Packaging unit:</b>	Units	Packaging	
	50 pcs.	Bag	
	1.000 pcs.	Carton	
<b>GTIN:</b>	<b>180W</b>	4049825000617	
<b>Storage:</b>	Store in a dry environment out of direct sunlight in original packaging, see also packaging. Shelf life: 10 years.		
<b>Disposal:</b>	When used as intended, the product can be disposed of in household waste and landfills and thermally recycled without releasing toxic substances. National regulations and laws must be followed.		